
Smart Lock User Manual



Special Attention:


- 1. Mechanical keys please keep outdoor, just in case keys lock in doors.
- 2. Please charge for the battery when low wattage alarm.
- 3. Reading this manual carefully before installation, and keep it for future reference.

1. Lock Structure



2. Mortise


For Aluminum Door



For Wooden Door & Security Door








Model : S31B


Material	Stainless Steel	
Suitable for Doors	Aluminum Door	
	Wooden Door	
	Security Door	
Mortise	All Types	
Door Thickness	30-80mm	
Size	280mm(H)*38mm(W) *25mm(T)	
Functions	APP Bluetooth Unlock	
	APP WiFi Unlock	
	Fingerprint Unlock	
	Password Unlock	
	Card Unlock	
	Key Unlock	
Fingerprint Sensor	Semiconductor Sensor	
Data Capacity	Unlimited	


3. Installation

3.1 Installation Diagram



3.2 Turn the handle





4. Specifications

Suitable for Models	S31B	
Materials	SS304	
Front Panel Lock Size	280*38*25mm	
Back Panel Lock Size	280*38*25mm	
Lock Weight	2.5KG	
Unlocking way	Bluetooth Fingerprint Password Card Mechanical key	
Colour	Silver black Golden	
Doors Applicable	aluminum door wooden door sliding door swing door	
Working Voltage	6V/4x AAA batteries	
Door Thickness to Fit	ness to Fit 30-80mm	
Data Capacity	Unlimited	
Working Temperature	-20℃-70℃	
Working Humidity	20%-90%	
Low Wattage Alarm	Less than 4.5V	

System Initialization

install the battery ,Long press the "Reset" button on the back panel for 5s, press

"000#", and the initialization is complete




5. Registration





- 5.1 Connect lock to the phone
- 1) Android mobile phone, please scan the left QR code as above
- 2) Apple mobile phone, please scan the right QR code as above
- 3) Register a new account (phone number or email) or login with an existing account.
- 4) Touch the lock screen, click "+ Add Lock"
- 5) The lock nearby will appear on the phone screen, Click "+"
- 6) Re-name the lock
- 7) The lock added successfully

Login	Register	∃ TTLock 9
 I8520265893 	© ×	+ Press to Add Lock
Login Forgot Password?		The Phone needs to be within 2 meters of the Smart Lock during the Pairing process.
	1-1	1-2



5.2 Unlock(The Admin unlock)

5.2.1 Bluetooth unlock

After mobile phone and door lock connected, Click " as show as figure 2-1 to unlock. (the phone is within 5meters from the door lock)

5.2.2 remote control unlock(Option)

After confirming that your phone and door lock are connected to the gateway, Click " 📀 " as show as figure 2-1 to unlock. You can unlock it anywhere you have a network. (How to set up the gateway to connect to your phone refer to step 5.3)

5.2.3 Bluetooth key remote authorization

Click on the " $\operatorname{Send eKey}$ " as shown in figure 2-1, you can send the eKey to other users of TTlock to authorize the unlock (the receiver must be download the APP and resiter an account) \rightarrow Enter recipient's account of TTlock, set the name and effective time of the eKey as shown in figure 2-2 \rightarrow Send \rightarrow The recipient's account has bluetooth unlock permission

5.2.4 The Admin password unlock

Click " [™] settings "as shown in figure 2-1→See Admin Passcode as shown in finger2-3→input Passcode on the

keypad of lock \rightarrow " #" to unlock.

5.2.5 Dynamic password unlock

Click " $\operatorname{Generate}_{\operatorname{Passcode}}$ "as shown in finger 2-1 \rightarrow finger 2-4 You can set the effective time and effective number of

passwords \rightarrow Generate password \rightarrow Input password to unlock.


5.2.6 unlock records


Click " $\underset{\text{Records}}{\overset{(1)}{\longrightarrow}}$ "as shown in finger 2-1 \rightarrow you can query your unlock record as shown in finger 2-5

Fingerprint unlock 5.2.7

Click " $\frac{1}{1}$ as shown in finger 2-1 \rightarrow Click " \rightarrow Add Fingerprint \rightarrow set the name and effective time of the fingerprint \rightarrow Start \rightarrow Place your finger on the sensor follow the instructions \rightarrow Add fingerprint OK \rightarrow Place your fingerprint on the sensor to unlock.

5.2.8 Card unlock








9


2-5

5.3 Set up the connection between the gateway and the phone(Option)

Light Status



Pair the Gateway with APP



▲ Notice: If times out, please power off and try it again.

Packing List

r				,i
Picture			User Manual	
Name	Front Panel	Rear Panel	User Manual	Mortise
Quantity	1	1	1	1
Picture				SMARTLOCK
Name	Strike	Pointed screw	Mechanical Key	Card
Quantity	1	4	2	2
Picture				
Name	Square Shaft	Spring	Fixing screws	Hexagon screw casing
Quantity	1	1	2	2
Picture				
Name	Gateway			
Quantity	1(Option)			

Guarantee

Customer name:	
Customer calls :	
Purchase date :	
Product name : _	
Product model :	

Note:

- 1) please keep this card so that you can use it when you need warranty service.
- 2) we provide you with a one-year warranty from the date of purchase.
- 3) this warranty service is valid for customers in any country in the world.